


# Wireless Thermostat Manual

User Guide Model : TP608RF



## About your thermostat

TP608RF is a modern touch type wireless thermostat. It can replace most common residential thermostat and is designed to be used with electric, gas or oil heating control system.

Unlike ordinary single unit design thermostat, this unit is a new type of thermostat separating the thermostat function into two units. Receiver and Control Center. The distance over 150M in the open air. It can be used to control boilers, thermal actuators, motorized valves etc.

Thermostat all passed CE and RoHS standard.

## Service

We offer the warranty of 24 months from the sales day. If it is not the problem of quality or beyond the warranty time, we will charge for the after-sale service.


## Technical Data of your thermostat

- Power source :Control Centre 2 AA batteries  
Receiver 95-240VAC±10% 50/60HZ
- Frequency band:868MHZ
- Relay contact:3A for water heating/gas boile heating  
16A for electric heating
- Room temperature setting range:5°C-35°C
- Working environment temperature range:0°C-50°C
- Storage Temperature range:-10°C-60°C
- Accuracy:0.5°C
- Control Center/Receiver Dimension : 86mm\*86mm\*15mm
- Installation:Wall mount or Desktop`

## Features of your thermostat

- Temperature display of Celsius
- Programming Period: 5+1+1, 6 separate periods per day.
- WIFI APP control with IOS&Andriod
- Anti-freezing protection
- Modern design similar as a cell phone.
- White/Black Colour option creates elegant life.
- Acrylic lenses to avoid the finger scratch.
- Touch Button makes simple operation.
- Large VA screen display with backlight is easy to read—even in the dark.
- One-touch temp control overrides program schedule at any time.
- Precise comfort control keeps temperature within 0.5°C of the level you set.
- Data memory when power is off.


## LCD Display Reference



## Operation

1. ⚡ Press this button to power on /off your thermostat
2. ⚡ Press this button to set min/hour/week
3. ⚡ Press this button to select manual /programm mode
  - ↳ **Manual mode:** Press ⚡ button to select manual mode. When you select manual mode, the symbol ⚡ will show in the bottom left corner. Press ⚡ buttons to change the desire temperature
  - ↳ **Program mode:** Press ⚡ button to select program mode. When you select this mode, the symbol ⚡ will show in the bottom left corner. Press ⚡ buttons over 5seconds to activate weekly program set mode. Press ⚡ button to select (5+1+1)six periods time and temp. When you set the Desire time and temp. Press ⚡ button to save the set and return back home screen.
  - ↳ **Temporary mode:** During program mode. If you need change the temp, The icon ⚡ will appear. The presetting program will return in next period
4. ⚡ **Child clock:** You could press ⚡ 7seconds to lock/unlock your thermostat
5. ⚡ **Holiday mode:** Press ⚡ 7seconds to enter holiday mode when power on. The ⚡ icon will display on left button, Short press ⚡ to set desire day and temp. Press ⚡ button to change day range 0-99 or desire temp. Press ⚡ button to save the set and return back home screen. Press ⚡ button to exit this mode
6. **Factory reset:** 1 weekly program reset, Press ⚡ button over 7seconds to enter program mode. Then press ⚡ over 7seconds to go to factory setting. The LCD will display "def" in the bottom right corner.  
2. Configuration menu reset. Press ⚡ button over 7seconds to enter configuration menu when power off. Then press ⚡ to go to factory setting. The LCD will display "def" in the bottom right corner.
7. **Low battery alarm**  
Low Battery symbol ⚡ will display on LCD when power <= 10%. APP will remind you to replace batteries  
⚡ flash when battery power use almost 99%, RF will stop working. You have to replace new batteries immediately

## Receiver button function



**1. Power Indicator (Red light):** Press SET button to power on/off the receiver. Power on RED light on. Power off the RED light off.

**2. Load indicator (Green light):** In normal operation, the load output is turned on. The green light will be on. When the load output is off, the green light will be off. When the green light quickly flashes, it indicates an external sensor error.

### 3. RF signal indicator (Yellow light).

A: Yellow light is always on. It means the receiver has paired with the transmitter. When power is off, press the SET button for 7 seconds. The RF light will turn on. Press the button again. The receiver will enter pairing mode. Yellow light will flash 3 times when pairing is successful with the transmitter.

B: Yellow light flashes quickly. It means the receiver has received a signal successfully. It will flash once when the receiver receives the signal from the transmitter each time.

C: Yellow light flashes slowly. It means the receiver has paired successfully with the transmitter.

### 4. Emergency output method (Manual output):

When the transmitter is broken or cannot control the receiver, you can use this method. Turn off the receiver. Long press the Set button. RF signal light (Yellow light) is on all the time. After 18 seconds, the load light (Green light) and RF light (Yellow light) are on at the same time. Emergency output will work. Short press Set to quit this function.

## Program Settings

When power is on, press  for 7 seconds to enter program mode. Press  to change the different items. Press   to set the relative values.

The order is Week-time-Temp (Monday-Friday, Saturday, Sunday=5+1+1) Each day has 6 periods setting.

Time display	Weekday(MON-FRI)		Weekend(Saturday)		Weekend(Sunday)	
	Time	Set Temp	Time	Set Temp	Time	Set Temp
Period 1	6:00	22°C	6:00	22°C	6:00	22°C
Period 2	8:00	16°C	8:00	16°C	8:00	16°C
Period 3	12:00	22°C	12:00	22°C	12:00	22°C
Period 4	14:00	16°C	14:00	16°C	14:00	16°C
Period 5	18:00	22°C	18:00	22°C	18:00	22°C
Period 6	22:00	16°C	22:00	16°C	22:00	16°C

## How to match code between transmitter with receiver?

Normally you don't need to match pair code. All match well in factory. Each pair will have the same series match numbers.

However, if your transmitter loses signal with your receiver, you can connect according to the following steps:

1. On your receiver, make sure the receiver is in pairing mode. When power is off, press the SET button for 7 seconds. Yellow light is on. It means the receiver has paired with the transmitter.

2. On your thermostat, press  and  for 7 seconds. The LCD will display: " --- ". After pairing is successful, the transmitter's LCD will display number (1-9 range all ok).

3. Transmitter's RF symbol  will be on it. Receiver's yellow light will flash 3 times.

### NOTE:

 Flash means RF not pairing code.

 Disappear means no RF signal.

 Always on screen means RF working normally.

## Configuration menu

Turn off the thermostat. Press  for 7 seconds to enter configuration mode. During this mode, short press  to change parameters. Press  to confirm the setting.

No.	Function	Press   to set	Default
1	Calibration	-9°C to 9°C	0°C
2	Dead Zone	0.5°C to 5°C	0.5°C
3	Lock	0: All buttons will be locked except the power button 1: All buttons will be locked	0
4	Minimum temperature setting	5°C to 20°C	5°C
5	Maximum temperature setting	20°C to 35°C	35°C
6	High temperature protection (external sensor only)	25°C to 70°C	45°C
7	Display Mode	0: Room temperature 1: Setting temperature	0
8	Low Temperature protection (Anti-Freeze Protection)	0: Off 1: On. When room temp = 5°C, heat on. When room temp is over 8°C, heat off	0
9	ECO mode	0: Off 1: On	0
10	ECO Temp set range	5°C to 30°C	16°C

### \*High temperature protection

1. When the external sensor detects the floor temperature is over 45°C, the thermostat will turn off the heat.

2. When you connect an external sensor, this function will work. In your thermostat, you can press  and  for 7 seconds to check the floor temperature. The app's settings can also check the floor temperature. The thermostat's LCD will display 'ERR' when the external sensor is broken or loose. The app will also alert about floor sensor errors.

If you don't connect an external sensor, then you can't check the external sensor's temperature both on the thermostat and the app.

## Wiring Diagram

