

Cleaning

Burner Cleaning Spray



[EG-Sicherheitsblatt](#)

Cleaning and degreasing spray for all severely dirty burner components.

- residue-free
- acid-free
- is not subject to the specific labelling of ASTV
- eliminates moisture
- can size 500 ml

Spray cleaner for repairs, maintenance and installation

Applications

Burner Cleaner eliminates all dirt containing oil, grease and wax from various surfaces and materials. Burner Cleaner cleans all metals, glass, ceramic and almost all plastics (thermoplastics such as PVC, plexiglass, polystyrol and lacquer coatings will corrode).

Burner Cleaner is used for:

- Cleaning and degreasing of burner components such as air-flow sensor plates, nozzles etc.
- Outer surfaces of the burner
- Cleaning and degreasing of all above-mentioned materials.

Packaging

Burner Cleaner is available in 500 ml aerosol cans.

Safety

The container is pressurized. Protect from sun and temperatures above 50° C. Do not open forcibly or burn, even when empty. Do not inhale the aerosol. Do not allow the contents to enter the waste water system. Do not spray people. Keep away from naked flames and incandescent materials. Keep away from sources of combustion – do not smoke -. Keep away from children. Only use in well-ventilated areas. In the case of contact with eyes, keep the eye open and rinse with lots of water. Contact an eye specialist if the irritation does not subside.

Disposal advice

Do not dispose of the can in the domestic waste. Discard the totally emptied can into the recyclable waste container (green dot)